

SPARE PARTS NUMBER - QUICK REFERENCE																				
PART NAME																				
set gaskets	80339	80339	80339	80339	81555	81555	81555	81556	81556	81556	81556	80582	81598	81598	81598	81598	81599	81599	81599	
set valve plate	80352	80352	80353	80353	81553	81554	81554	81553	81553	81554	81554	81557	80965	80965	80966	80966	80966	80966	80966	
set piston	80344	80345	80346	80347	80297	80298	80299	80296	80297	80298	80299	80299	80943	80943	80944	80945	80943	80944	80945	
set connecting rod	80340	80340	80340	80340	8422	8422	8422	8422	8422	8422	8422	80840	81085	81085	81085	81085	81320	81320	81320	
set piston-connecting	80348	80349	80350	80351	80302	80303	80304	80301	80302	80303	80304	80844	80946	80947	80948	80949	81187	81188	81189	
set rear bearing flange	80341	80341	80341	80341	81557	81557	81557	81557	81557	81557	81557	80581	81381	81381	81381	81381	81381	81381	81381	
set centre bearing bush	81411	81411	81411	81411	81364	81364	81364	81364	81364	81364	81364	81446	81367	81367	81367	81367	81368	81368	81368	
set rear bearing flange bush	81412	81412	81412	81412	81371	81371	81371	81371	81371	81371	81371	81446	81368	81368	81368	81368	81369	81369	81369	
set oil strainer	80284	80284	80284	80284	81384	81384	81384	81384	81384	81384	81384	80785	81384	81384	81384	81384	81384	81384	81384	
set oil sump heater	8028	8028	8028	8028	8028	8028	8028	8028	8028	8028	8028	8028	81252	81252	81252	81252	81252	81252	81252	
set crankshaft	80342	80342	80342	80342	80312	80312	80312	8045	8045	8045	8045	8045	80951	80951	80951	80951	80952	80952	80952	
set oil pump	81192	81192	81192	81192	81192	81192	81192	81192	81192	81192	81192	81192	80950	80950	80950	80950	80950	80950	80950	
set fixing parts	8983	8983	8983	81489	81489	81489	81489	81490	81490	81490	81490	N/A	80938	80938	80938	80938	80939	80939	80939	
suction Filter	50052	50052	50052	50052	50052	50052	50052	50035	50035	50035	50035	50035	3370	3370	6574	6574	50685	50685	50685	
set terminal board	80579	80579	80579	81566	81566	81566	81566	81566	81566	81566	81566	80579	8949	8949	8949	8949	8949	8949	8949	
set shut off valve suction	8859	8859	8859	8859	8829	8829	8829	80863	80863	80863	80863	8084	8082	8082	8398	8398	8087	8087	8087	
set shut off valve discharge	80343	80343	80343	80343	8859	8859	8859	80861	80861	80861	80861	8829	8084	8084	8084	8084	8082	8082	8082	
set motor normal		80355	80356	80356	81558	81558	81558	81559	81559	81560	81560	N/A	81391	81393	81392	81393	81393	81394	81395	
set motor heavy duty	80355	80356	80357	80357	81558	81559	81559	81561	81561	81561	N/A	81393	81393	81393	81393	81394	81395	81396	81396	
set CR/SU assay 230v	N/A	N/A	N/A	N/A	N/A	N/A	N/A	81372	81372	81372	81372	8821	81372	81372	81372	81372	81372	81372	81372	
set CR 230v with cyl. Cover	N/A	N/A	N/A	N/A	N/A	N/A	N/A	81542	81542	81542	81542	8106	81386	81386	81386	81386	81386	81386	81386	
set start unloader ESS 25 / 230v	N/A	N/A	N/A	N/A	80374	80374	80374	80374	80374	80374	80374	80374								
set start unloader ESS 38 / 230v													80464	80464	80464					
set start unloader ESS 63 / 230v																80465	80465	80465		
set start unloader ESS 72 / 230v																			for norm. -80466	
set start unloader ESS 106 / 230v																			for 4 - 80466	
																			for stong - 80467	
																			for 4S - 80467	
																			80467	
																			80467	

set gaskets	80339	80339	80339	80339	81555	81555	81555	81556	81556	81556	81556	80582	81598	81598	81598
set valve plate	80352	80352	80353	80353	81553	81554	81554	81553	81553	81554	81554	81557	80965	80965	80966
set piston	80344	80345	80346	80347	80297	80298	80299	80296	80297	80298	80299	80299	80943	80943	80944
set connecting rod	80340	80340	80340	80340	8422	8422	8422	8422	8422	8422	8422	80840	81085	81085	81085
set centre bearing bush	81411	81411	81411	81411	81364	81364	81364	81364	81364	81364	81364	81446	81367	81367	81367
set rear bearing flange bush	81412	81412	81412	81412	81371	81371	81371	81371	81371	81371	81371	81446	81368	81368	81368
set oil strainer	80284	80284	80284	80284	81384	81384	81384	81384	81384	81384	81384	80785	81384	81384	81384
set oil sump heater	8028	8028	8028	8028	8028	8028	8028	8028	8028	8028	8028	8028	81252	81252	81252
set oil pump	81192	81192	81192	81192	81192	81192	81192	81192	81192	81192	81192	81192	80950	80950	80950
set fixing parts	8983	8983	8983	81489	81489	81489	81489	81490	81490	81490	81490	N/A	80938	80938	80938
suction Filter	50052	50052	50052	50052	50052	50052	50052	50035	50035	50035	50035	50035	3370	3370	6574

SPARES LIST FOR

- HG12P, HG22e, HG34e (DK 057), HG44e, HG56e, HG66e, HG88e, HG12P/60-4S, HG12P/75-4S,
- HG12P/60-4S HG12P HG12P HG22e HG22e/160-4S
- HG22e/190-4S HG34e HG34e HG34e HG34e/380-4S
- ALLUMINIUM HG34e/380-4S HG44e HG44e HG44e/665-4S